

Valved Fittings

Install between a pressure gauge and the process and isolate the process from the gauge to perform a calibration of the gauge. After completing the calibration open the valve and place the gauge on-line, all without blowing down the system.

Features

- * Use whenever there is a gauge that needs frequent calibration or verification



Valved Fittings

Select a model for more information

Model	Material	End 1	End 2	Block Valve	Vent Valve	Working Pressure
QTVF-000B	Brass	1/4" Male NPT	1/4" Female NPT	Yes	No	3000 PSI
QTVF-000B-2F-2F	Brass	1/4" Female NPT	1/4" Female NPT	Yes	No	3000 PSI
QTVF-000B-2F-2M	Brass	1/4" Female NPT	1/4" Male NPT	Yes	No	5000 PSI
QTVF-000S	Stainless Steel	1/4" Male NPT	1/4" Female NPT	Yes	Yes	3000 PSI
QTVF-000S-2F-2F	Stainless Steel	1/4" Female NPT	1/4" Female NPT	Yes	No	3000 PSI